



**PeiZen, Inc.**

1227 Flynn Road, Suite 302

Camarillo, CA 93012

Phone: (805) 484-2454, FAX: (805) 383-5909

E-mail: [hlee@flatmonitors.com](mailto:hlee@flatmonitors.com)

Websites: [www.flatmonitors.com](http://www.flatmonitors.com) and [www.peizen.com](http://www.peizen.com)

Assembly Instructions for  
Q-1718-RK Rackmount Kit onto  
Samsung 214T-Black 21.3" or equivalent TFT LCD Monitor

Tools needed:

1. 11/32 socket wrench
2. No. 2 Phillips screw driver
3. Tie wrap tool
4. Wire cutter, angle tipped is recommended.

Procedures:

1. Spread the ¼" white foam pad that comes with the packing material on a tabletop.
2. Lay the monitor facing down on the soft foam pad. Remove the stand by removing four metric screws from its stand. Store the stand and the metric screws in the original box. In case of warranty service, you will need to put the monitor back into its original configuration.
3. Position the Q-1718-RK, as shown below, on the back of the monitor. Try to pick the best set of four VESA (100 mm centered) mounting holes to mount the monitor so that it will appear even between the top and bottom edges.



4. Insert a 4 mm X 16 mm metric screw, a No. 8 lock washer, and a No. 8 flat washer into each of the four VESA mounting holes.
5. The cable clamps provided are used for tying down the power cable, digital cable, and the SVGA monitor cable. Tighten the 8-32 lock nuts with 11/32 socket wrench.
6. Tie wraps are also provided if you need them. Trim all tie wraps with a wire cutter.



7. Use the black 10-32 screws to secure the rackmount assembly to your rack.



Note: The offset between the monitor bezel and the mounting plate is thickness of the monitor.

8. If you have any questions or comments, please call Harry Lee, 805-484-2454 or e-mail to [hlee@flatmonitors.com](mailto:hlee@flatmonitors.com).